How to deploy

Security Training Site to azure

1. Prerequisites

Need to have:

- Azure account
- GitHub account
- MS SQL Server Management Studio

2. Create database and SQL server

On azure portal (https://portal.azure.com/) go to:

+ New / SQL DataBase and set configuration details.

SQL Database --> Database name
Resource group FP


Server --> Server name securitytrainingserver

Server admin login DogCatFrog

Password {your db server password}

securitytrainingdb


Location West Europe



3. Run SQL script.

On azure go to:

All resources / securitytrainingserver / Show firewall settings / Add client IP / save




Login on MS SQL Server Management Studio as:

Server name securitytrainingserver.database.windows.net

Login DogCatFrog@securitytrainingserver

Password {your db server password}


Run 'SecurityTraining-Create Tables-Azure.sql' script to create tables.



4. Create App Service Plan

On azure type App Service Plan in search area and click Create

+ New / 'App Service Plan' / App Service Plan / Create




Enter Details:

App Service planServicePlan

Resource Group FP

Location West Europe

Pricing tier F1 Free



5. Create Web App


+ New / Web + Mobile / Web App

Fill details

App Name SecurityTrainingSite

Resource Group FP


App Service Plan ServicePlan



6. Get publishing profile


All resources / SecurityTrainingSite / Get publishing profile

Copy 'SecurityTrainingSite.PublishSettings' to your project folder and commit changes to GitHub.



7. Choose Development Source


All resources / SecurityTrainingSite / Settings / Development source



8. Configure Connection String

Get Connection string from created data base

All resources / securitytrainingdb / Settings / Properties / Connection strings / ADO.NET



Configure connection string

All resources / SecurityTrainingSite / Settings / Application settings / Connection strings

Name DefaultConnection

Value Server=tcp:securitytrainingserver.database.windows.net,1433;Data Source=securitytrainingserver.database.windows.net;Initial Catalog=securitytrainingdb;Persist Security Info=False;User ID= DogCatFrog@securitytrainingserver;Password={your_password};Pooling=False;MultipleAc tiveResultSets=False;Encrypt=True;TrustServerCertificate=False;Connection Timeout=30;

